TCI Engineering

Engineering

Sensitivity: Internal & Restricted

Table of contents

Contents

1 Introduction 8

2 System requirements 8

3 Downloading and installing software and the documentation package 9

4 Attention points 10

4.1 General 10

4.2 DALI 10

4.3 NFC interface 10

5 The software interfaces 11

5.1 DALI 11

5.2 NFC 12

12

6 Starting software 13

6.2 Application mode selector 16

7 Selecting the interface 17

7.1 Interface Auto detection 17

7.2 Interface Manual selection 17

8 Working with the USB2DALI interface 19

8.1 The main application window 19

8.2 Managing the DALI network 19

8.2.1 Identifying devices 19

8.2.2 Selecting devices for communication 22

8.2.3 Managing user-defined groups 23

8.2.4 Managing groups 24

10 Working with the NFC interface(s) 32
10.1 The main application window 32
10.2 Scanning a NFC device 32
10.2.1 Identifying devices 32
10.2.2 Auto read 33
10.3 Selecting devices for communication 33
10.4 Starting communication 33
11 Working with software 34
11.1 Viewing device properties 34
11.2 Communicating with a device 34
11.3 Configuring device features 35
11.3.1 0-10V / 1-10V (SR bridge) 39
11.3.2 0-10V / 1-10V (LED driver) 40
11.3.7 Adjustable Light Output 45
11.3.8 Adjustable Output Current 46
11.3.11 Adjustable Startup Time 48
11.3.12 AmpDim 48
11.3.13 Change Logarithmic in Linear dimming-curve with DALI commands 49
11.3.14 Auxiliary Power Supply Voltage 49

11.3.18 Constant Light Output 51

11.3.22 Corridor Mode 59
11.3.23 DALI 102 60

11.3.25 DALI 202 63

11.3.28 DALI Power Supply 66
11.3.29 Daylight override / Daylight switching 66
11.3.30 DC Emergency 67
11.3.31 Device Info 67
11.3.32 DiiA specification DALI Part 253 - Luminaire Maintenance 68
11.3.33 Dimming Interface 68
11.3.34 Driver addressing 70
11.3.35 Driver Temperature Limit 70
11.3.36 Driver Temperature Limit for Lock 71
11.3.37 Dwell Time 72
11.3.38 Dynadimmer 73

11.3.41 End Of Life indication 80

11.3.50 Light Source Operating Hours 88
11.3.51 LineSwitch 88
11.3.52 Load Fault Indicator Thresholds 90
11.3.54 Luminaire (Fixture) Information 92
11.3.57 Min Dim Level 95
11.3.59 Module Temperature Protection 97
11.3.61 NTC on LEDset 98
11.3.64 OEM Write Protection 101
11.3.70 SR Power Supply 105
11.3.71 Step Dimming 106
11.4 Using the features summary 108
11.5 Saving and opening a feature configuration file 108
11.6 Configuring a single device 111
11.7 Configuring multiple DALI devices (simultaneously) 111
11.8 Configuring multiple DALI devices (consecutively) 112
11.8.1 Software 112

11.10 Offline feature configuration preparation 113
11.11 Sending DALI commands 114
11.12 Traceability 116
11.13 Working with DALI command scripts 116
11.14 Querying devices 119
11.15 Accessing Diagnostics 120
11.15.1 Diagnostics 120
11.15.2 Set Lamp On Time 131
11.16 Accessing Energy Meter 132
11.16.1 Energy Meter 133
11.16.2 DiiA specification DALI Part 252 - Energy reporting 133
11.17 Accessing Installer 134
11.17.1 Coded Light Randomize 134
11.18 Working with the DALI Sniffer 135
11.18.1 Sniffing with multiple interfaces 136

11.21 The logging window 140
11.22 Setting preferences 140
11.22.1 General preferences 141
11.22.2 DALI 143
11.22.3 Updates 144

11.23 Manually selecting the USB2DALI interface 145
11.24 Enabling/Disabling the power supply of the USB2DALI interface 146
11.25 Supported features 146
11.26 Device-specific technical descriptions 150
11.27 Error handling 150
11.27.1 Reporting and correction of errors/warnings when reading from a feature configuration file 150

11.27.2 Reporting of errors when reading from a device 150
11.27.3 Reporting of errors when entering incorrect values in a feature 150
11.28 Troubleshooting 150

1. Introduction

Today's customer demands more flexibility and customization possibilities than
"physical configurations" can offer. With configurable devices (drivers or sensors) with built-in controls or separate controllers you can configure the luminaire's behavior.
You can control output levels, or even pre-configure dynamic dimming on the client's request; either directly in the factory or during installation on location. All you need is ONE intuitive tool that when plugged into a device can calibrate ALL the different functions required by any lighting solution.

Creating the perfect lighting solution has been made very easy with TCI software.

With TCI software, you can configure all features that are supported by a device. A feature typically belongs to one or two product groups, but this does not mean that every device from a product group does support all features.

2. System requirements

The minimum system requirements for using TCI software are:

- PC or laptop with Microsoft Windows 8, 8.1, 10, 11
- USB 2.0 ports:
    - Two free USB 2.0 ports for use with USB2DALI interface
    - One free USB 2.0 port for use with NFC interface

A zip-file can be downloaded from our website p-file contains the following files:

- TCI software.exe (executable/installer)
- TCI Workflow.exe (executable/installer)
- GettingStarted.pdf (document)
- UserManual.pdf (document)
- RELEASE_NOTES.txt (document)

The software installation file is the installer for the full version of software. This document applies to this version of the software.
The TCI Workflow installation file is the version of software which is meant to be used in a production environment.

To install the software, launch the installer for the desired version and follow the instructions on your screen.
The installation wizard will guide you through the process of installing the software and will ask you where the software needs to be installed. At the end, it will give you the option to immediately start software

4.1 General

Before starting software, make sure that the correct interface (USB2DALI, or NFC) has been connected to your computer.

When upgrading the Windows Operating System, make sure the connection settings are correct when using software again.

When starting multiple instances of software for parallel configuring, make sure every instance of software uses another interface. The unique id of an interface is shown in the Connection Settings window where the interface port is selected. Also, for the currently selected interface the unique id can be found in the About box and in the tooltip of the connection status indicator in the status bar at the bottom-right part of software.

4.2 DALI

Lighting applications with DALI devices can be seriously affected by the presence/absence of the DALI short address. Make sure the DALI short address is as you expect, after finishing working.

4.3 NFC interface

For NFC there are different interface which can be used for communication (see §6.3): 127095A or 127101.

5

5.1 DALI

The USB2DALI interface is the interface between PC and the DALI devices. It has a mini- USB input connector and two parallel DALI output connectors. The USB2DALI interface status is indicated by three LED's located near the mini-USB connector.

The USB2DALI interface is supplied with a USB cable that can supply the DALI network with up to 220mA. It is advised to only use the supplied cable, in order to assure correct functioning of the USB2DALI interface.

- Safety: Class II, double insulated
- DALI open circuit voltage (when power supply enabled): 15V



or

5.2 NFC

The NFC interface are USB devices which interface between the PC and NFC devices:

127095A

127101

Before starting make sure that the correct interface (USB2DALI, or NFC has been connected to your computer.

TBD

TBD

6.2 Application mode selector



Once the activation process is done and when starting software the first window that appears is the **Application Mode Selector**. Here, you can choose an application mode, based on the tasks you would like to perform. The application window also has links to the documentation.

One of the modes is **Single device programming**. This mode simplifies some parts of the device configuration workflow when only one device has been connected.
Single device programming is discussed in detail in chapter 0.

If you know that you will mostly perform the same tasks in the future, you can select **Remember my choice** and then click the appropriate application mode. Software will record your choice and The **Application Mode Selector** will not appear again the next time software is started.

You can always go back to the **Application Mode Selector** by selecting **View** ⍰ **Application Mode Selector** from the main application window.

7. Selecting the interface

After the **Application Mode Selector** you must select the interface (USB2DALI or NFC) to work with.

7.1 Interface Auto detection

Interface can be automatically detected in case of DALI and NFC.

On first start software will detect whether DALI or NFC interfaces are connected to your PC or laptop.

- When only one interface is connected this one will be automatically chosen.
- Otherwise the Connection Settings window will appear.

Whenever software is started again and a previously selected interface is not connected anymore the following selection or action will take place:

- When only one interface is connected (independent of the type of interface) this one will be automatically chosen.
- When two interfaces are connected and one of them is of the same type as the previously selected interface this interface is automatically selected.
- Otherwise the Connection Settings window will appear.

Connecting multiple similar NFC interfaces is currently only supported when using a 127095A or 127101 interface.

Notice! Whenever software is started again, if the previously selected interface is not either Dali or NFC the auto detection will not work and software will start with the previously selected interface.

7.2 Interface Manual selection

First select the protocol: **DALI** or NFC, when needed also indicate the selected interface and port or reader (in case of NFC).



This protocol can always be changed later, by going to the **Tools Connection settings.**

Notice! For DALI and NFC the unique id of the interface is shown at the port/reader selection. This, to be able to identify which interface is used by which software instance (when configuring devices in parallel using multiple instances of software).

When a selected interface contains an outdated firmware version, software will show a message that it is unable to connect to the selected interface:



8. Working with the USB2DALI interface

Before using software with the USB2DALI interface make sure that all devices that need to be commissioned are connected to the mains and the DALI network. Finally the DALI network must be connected to one of the DALI connectors of the USB2DALI interface.

8.1 The main application window

If in the Application Mode Selector screen **All** is selected as application mode, the program will start as follows:



A more thorough explanation on how to communicate with devices can be found in chapters 12.2, 12.3, 12.11 and 12.12 of this manual.

8.2 Managing the DALI network

The **Network** panel is used to manage the connected DALI network. A number of tasks can be performed in the **Network**, each of which is detailed below.

8.2.1 Identifying devices

When starting software, DALI devices connected to the USB2DALI interface are not automatically identified. There are two methods for identifying the devices with corresponding buttons in the **Network** on the left-hand side of the application window: **Scan network** and **Commission**.



Note! A **Scan network** or **Commission** execution will place all found devices into manufacturer specific operating mode. Take care of this in case you need to use a connected driver in the DALI standard operating mode!

8.2.1.1Scan network

There are two ways to scan a network: by short address or by random address. You can choose which method to use by going to **Tools->Preferences->DALI scanning**.

The key differences between scanning by short address and scanning by random address are the following:

- Scanning by short address will not change the random addresses of the connected devices. You should use this method if random addresses should not be affected. Additional user input might be required to find all connected devices (see below).
- Scanning by random address will change the random addresses of all connected devices. Any devices that do not have a short address yet will be assigned one automatically. Any devices that share the same short address will be automatically assigned (new) unique short addresses. This method is most likely to find all connected devices without user intervention.

Scan by short address. This method queries all short addresses without changing anything in the configurations of the connected devices. If all connected devices have a unique short address, this method will be able to find all devices. If, however, some devices share the same short address, or if there are devices without a short address (uncommissioned devices), additional decisions need to be made.

The following situations can occur while scanning a network by short address:

- There are uncommissioned devices. You will see the following dialog:



By clicking **Yes**, the uncommissioned devices will be commissioned. As a side effect, the random addresses of all connected devices will be changed.
By clicking **No**, no additional actions will be done and the **Network** will not display all devices.

- There are devices with the same short address. You will see the following dialog:



By clicking **Yes**, the devices that have the same short address will be recommissioned. As a side effect, the random addresses of all connected devices will be changed.
By clicking **No**, no additional actions will be done and the **Network** will not display all devices. Errors are likely to occur, indicated by a warning icon next to the name of the device(s).

- There are uncommissioned devices AND devices with the same short address. You will see the following dialog:



By choosing the first option, all uncommissioned devices will be commissioned, and all devices with the same short address will be recommissioned. By choosing the second option, only the uncommissioned devices will be recommissioned. By clicking **Cancel**, no additional actions will be done and the **Network** will not display all devices. Errors are likely to occur, indicated by a warning icon next to the name of the device(s).

Scan by random address. This method re-initializes the random addresses of all connected devices. If there are any uncommissioned devices, or devices that have the same short address, these devices will automatically be (re)commissioned.

8.2.1.2 Commissioning

All devices are given a new unique short address, starting at 0. Be aware that existing short addresses are erased and new short addresses are re-assigned to all connected devices. This procedure ensures that all devices have a short address and that there are no duplicate short addresses.

After commissioning or scanning the network, the list of identified devices is shown in the **Network**.

8.2.2 Selecting devices for communication

After having commissioned or scanned the network, the **Network** shows all devices present in the DALI network.



By clicking a device you will make that particular device the active one, meaning that all commands will be sent to this device only, and will be ignored by all other devices.

Besides selecting a single device for communication, it is also possible to communicate with groups of devices. The options are:

- All devices in the network. Select **All devices**. All commands will now be sent as broadcast commands. Note that unidentified but connected DALI devices will also respond to commands.
- All user-defined groups. Select **User-defined groups**. All commands will now be sent to devices that belong to a user-defined group. User defined groups are explained in the section 9.2.3.
- A specific user-defined group. Expand **User-defined groups** and select the desired user-defined group. All commands will now be sent to devices that belong to this specific user-defined group.

8.2.3 Managing user-defined groups

Using the **Network**, devices can temporarily be grouped into user-defined groups. The purpose of user-defined groups is that they facilitate easy clustering so that a number of devices can be addressed simultaneously.

The user-defined groups are lost when software is closed.

A new user-defined group can be created by right-clicking **User-defined groups** and selecting **Add new group**.



Alternatively choose **Actions** ⍰ **Add user-defined group**. A new group is created with a default name. To add a device to a user-defined group, right-click the device, select **Add to custom group** and select one of the available user-defined groups.
Alternatively, the device can be dragged onto the desired user-defined group to add it to that group.

To immediately add a device to a new user-defined group, right-click a device and select **Add to user-defined group** and select **Add new group**.



The user-defined group will be created and the selected device will be added to the newly created user-defined group.

To rename a user-defined group, right-click the group and select **Rename**. This will set the user-defined group to edit mode so that the new name can be entered.



To remove a device from a user-defined group, right-click the device in the group and select **Remove**.
To remove an entire user-defined group (including its devices), right-click the group and select **Remove**.



Note! The number of devices in a user-defined group is limited to 64.

8.2.4 Managing groups

Once all the devices in the DALI network are commissioned, i.e. have a unique short address, it is possible to work with DALI groups.

Select the **Groups** tab and click **Scan groups.** After having scanned the network for groups, the **Groups** tab shows all the DALI groups and the found devices for every group.



DALI groups are much more comprehensive than user-defined groups. The important difference is that with DALI grouping information is stored in the devices themselves. Therefore, DALI grouping is more permanent than user-defined grouping.

By clicking on a device you will make that particular device the active one, meaning that all actions will be performed on this device only, and will be ignored by all other devices.

The options are:

- With a right-click on an un-grouped device you can:
  - **Identify** the device
  - **Add to,** add the device to one group
  - **Configure…**, add device to multiple groups



- With a right-click on a device in a group you can:
    - **Identify** the device
    - **Add to,** add the device to one other group
    - **Configure…,** add/remove device to/from multiple groups
    - **Remove**, remove device from current group



Besides selecting a single device for communication, it is also possible to communicate with a group of devices.

The options are:

- With a right-click on a group you can:
    - **Identify** the devices in the group
    - **Configure…**, add/remove multiple devices to/from the group
    - **Clear group**, remove the devices from the group



Note! The number of devices in a DALI group is limited to 64.

TBD

TBD

TBD

10. Working with the NFC interface(s)

10.1 The main application window

If in the Application Mode Selector screen **All** is selected a s application mode, the program will start as follows:



10.2 Scanning a NFC device

The **Network** panel is used to manage the scanned NFC devices. A number of tasks can be performed in the **Network** panel, each of which is detailed below.

10.2.1 Identifying devices

The NFC device near the NFC interface is not automatically known by software. To get the device click **Scan for device**: a pop-up will appear indicating the device must touch the interface.



Touch and hold the device close to the NFC interface until the scan has completed. The scanned device will be shown in the **Network** panel.

10.2.2 Auto read

After a device gets selected all features are shown on the **Features** tab and auto read gets activated. Auto read automatically start reading the configuration of all features. Progress is shown as described in chapter 12.2

10.3 Selecting devices for communication

After having scanned the NFC device, the **Network** panel shows the device. By clicking on a device you will make that particular device the active one, meaning that all actions will be performed on this device only, and will be ignored by all other devices.

10.4 Starting communication

In order to communicate with a NFC device, the device has to touch the NFC interface. Before starting the communication software will show a pop-up when the device is not near the NFC interface. This pop-up waits until the device and the NFC interface touch, or disappears after 20 seconds. After touching the action will be executed. Touch and hold the device close to the NFC interface until all communication has finished.



11. Working with software

11.1 Viewing device properties

Whenever a device is selected in **Network**, the **Properties** display a number of details for the selected device.

Properties	
Selected	SIRIO SQ 75W/300-1000 4PN
Version	1.0
DALI Ed	2.0
Hardware version	3.1
Firmware revision	6
Product code	000000145060

11.2 Communicating with a device

Initiating communication with a device is done by first selecting the device (left-click the device in **Network**) and then clicking **Read**, **Write** or **Reset** on the toolbar.



When the **Commands** tab or the **Scheduler** tab is active, these buttons are unavailable. When the **Query** tab is active, all queries are executed when clicking **Read**. When the **Diagnostics** tab is active, all diagnostics information is read (if available in the selected device) when clicking **Read**. The **Write** action is only available on the **Diagnostics** tab when the selected device has 1 or more features. When the Energy Meter is active, all data regarding **Energy Meter** is read (if available in the selected device) when clicking **Read.** When the **Device features** tab is active, the **Read** and **Write** actions are available. The **Reset** action is only available on the **Device features** tab when the selected device has 1 or more features that are resettable. The **Reset** action will set a feature to its factory defaults.

Reading, writing and resetting will always take a few seconds. Operation progress is shown on the status bar of the main application window. On the **Device features** and **Diagnostics** tab, per-feature progress is shown on each of the feature selection tabs. When all information has been successfully read or written, a green tick mark will appear and the text **Status: OK** is shown. If anything goes wrong, a red icon and the text **Status: failed** is shown. When on the **Device features** tab, point your mouse to each status icon to see a more detailed description of the communication result.

Apart from using **Read** and **Write** on the toolbar, you can directly send DALI commands. This can be done on the **Commands** tab and the **Scheduler** tab.

In the **Preferences** window it is possible to enable extra verification when writing (see chapter 12.22).

11.3 Configuring device features

You can configure all features that are supported by a specific device. For any device selected in the **Network**, the **Device features** tab displays the set of device features that corresponds to this device. Upon selecting another device, the **Device features** tab will be updated as well. This mechanism ensures that only the features supported by the selected device can be configured.

The **Device features** tab has a panel with a column of tabs on the left-hand side. Each feature has its own tab. For most devices a **Summary** tab is available as well.



To make sure that the feature information in the **Device features** tab corresponds to the selected device, click **Read** on the toolbar.



Note that some features might be OEM Readout-protected. OEM Readout-protected features are indicated by a padlock icon in the **Read feature configuration** window.



If an OEM Readout-protected feature is read, a dialog will appear asking for an access level and a password.



After providing a correct access level and password, and clicking **OK**, the OEM Readout-protected features will be read. By clicking **Cancel** none of the selected features will be read. If an incorrect access level and/or password were provided, the OEM Readout-protected features will receive a status icon indicating failure (see below).

To make sure that the feature information is stored in the selected device, click **Write** on the toolbar. If you want to reset certain features to its default settings, click **Reset** on the toolbar. Be aware that you need to click the **Read** button afterwards to reload the reset values.

Note also that some features might be OEM Write-protected. OEM Write-protected features are also indicated by a padlock icon in the **Write feature configuration** window.





Also note that you must select a check box to indicate that the device already has an OWP password configured. Software does not know this, because the configuration of a device is not always read before a Write action takes place. When the check box is selected and the **Write** button is clicked, a dialog will appear asking for a password. When the OWP configuration was already read, TCI knows the current OWP configuration and the check box will not be shown. In that way, TCI will show the password dialog only in case if OWP is enabled in the device and a write protected feature is selected.



After providing a correct password and clicking **OK**, the OEM Write-protected features will be written. By clicking **Cancel** none of the selected features will be written. If an incorrect password was provided, the OEM Write-protected features will receive a status icon indicating failure (see below).

For **Read**, **Write** and **Reset** actions, status icons will be shown when a feature is being read or written. There are four different colors used for the icons: red, orange, green and grey.

Red means that the read or write action failed. The green icon indicates that reading or writing was successful and that all the data was sent to the driver. This does not mean that all data is actually received (see Write and Verify in chapter 12.18.1). The grey icon is used to display that the read or write action is pending for the specific feature. An orange icon indicates that the last write action for the feature was not

successful and that the feature might not be configured correctly; the orange indicator is only applicable for NFC devices.



Read Write Reset Read

In the following sections you will find an overview of all supported device features in alphabetical order. Features typically belong to one or two product groups, but this does not mean that every device belonging to a certain product group will automatically support all of its features listed here. For an overview of supported device features see **Supported features**.

11.3.1 0-10V / 1-10V (SR bridge)

Product group

CONTROL



11.3.1.1 Description

The 0-10V interface requires special configuration to match the 0-10V (or 1-10V) dimming curves of the connected drivers. The SR Bridge needs to correctly and accurately translate the DALI arc power commands to the correct 0-10V dimming voltages for the connected drivers such that the appropriate LED driver output current is achieved. This feature is used to configure the dimming curve by either selecting a predefined fixed curve or specifying a curve manually.

11.3.1.2 Usage

Use the drop down box to select the 0-10V (or 1-10V) curve that should be used for the SR Bridge. There are four fixed curves (1-10V curved, 0-10V linear, 1-9V linear and 0-10V logarithmic) selectable and there is a possibility to select the **User specified** option.

Selecting the 'User specified' ZTV curve makes the **User specified curve** properties visible which can be used to construct a specific 0-10V (or 1-10V) curve. Both the **Dim level** and **0-10V / 1-10V** values can be changed to create a specific 0-10V (or 1-10V) curve.
Note! 0-10V linear curve also includes the European 1-8V linear curve.

11.3.2 0-10V / 1-10V (LED driver)

Product group

LED



11.3.2.1 Description

Use this feature to set the minimum dim level when using 1-10V.

11.3.2.2 Usage

- Use the slider or the text field to select a value. The value represents the light level.
- Use the drop down box to select the wanted curve selection (0-10V linear, 1- 9V linear, 1-10V curved or 0-10V logarithmic). The curve selection is device dependent. **Note!** 0-10V linear curve also includes the European 1-8V linear curve.
- Use the Enable dim to off checkbox to enable or disable the dim to off functionality.
- Use the first drop down box to select the wanted fade on time value. This value represents the time to turn on and start dimming up to target dim level.
- Use the second drop down box to select the wanted fade off time value. This value represents the time to start dimming down until the light is off.

TBD

TBD

TBD

TBD

11.3.7 Adjustable Light Output

Product group

LED



11.3.7.1 Description

Use the Adjustable Light Output (ALO) feature to regulate the light output to a desired optimum value. You can create a “virtual lamp” with output different than what the standard wattages offer.

11.3.7.2 Usage

Select the **Enable** check box to use this feature. Use the slider or the text field to select an **ALO** value. The value represents the light level. The **ALO min** value (only available for LED devices, not available for all devices) can be used to set the lowest possible ALO value.

11.3.8 Adjustable Output Current

Product group

LED



11.3.8.1 Description

Use this Adjustable Output Current (AOC) feature to adjust the output current to a desired optimum value. You can create a “virtual lamp” with output different than what the standard wattages offer.

11.3.8.2 Usage

The current can be set in two ways:

- Select the **External Rset** check box: Adjustment of the output current is not configured using software, but the value of an external resistor adjusts the output current

OR

- Use the slider or the text field to select a value. The value represents the nominal output current.

TBD

11.3.11 Adjustable Startup Time

Product group

LED



11.3.11.1 Description

At power on, the fast fade-up of light can be unpleasant in certain applications. To avoid such a situation, the device fade-up time at startup can be adjusted.

11.3.11.2 Usage

Use the slider or the text field to select a value. The value represents the start fade-up time in milliseconds.

11.3.12 AmpDim

Product group

HID, LED



11.3.12.1 Description

Use this feature to adjust the light output of a lamp by adjusting the mains voltage of the device.

11.3.12.2 Usage

Select the **Enable*** check box to use this feature (note that LED devices do not have this check box). Drag the points or the lines in the graph to create the desired configuration. Alternatively, use the table to directly enter values.

Note! For a detailed technical description of the characteristics of the device model, like constraints and limitations, please refer to **Device-specific technical description**.

* **Note!** If the device supports interface selection, then this feature can only be enabled through the interface selection and the enable will not be shown here.

11.3.13 Change Logarithmic in Linear dimming-curve with DALI commands

Product group

LED

11.3.13.1 Description

With the following commands a logarithmic dimming curve (default) can be changed in a linear dimming curve.

11.3.13.2 Usage

The logarithmic dimming curve is default.

To set the linear dimming curve, the command SELECT DIMMING CURVE must be used. This is a command in the so-called Application Extended Command Set.
The sequence of commands to follow is:

DTR(1)	(Write value “1” into DTR, 1 is indicating Linear curve)
ENABLE DEVICE TYPE(6)	(Select the Application Extended Command Set for DALI 207)
SELECT DIMMING CURVE	(Set the dimming curve to the value in DTR)

It is possible to write these commands via software (in the “Commands” tab or with a .mos file in the “Scheduler” tab)
Important is to know that the DALI command “RESET” will reset the dimming curve back to logarithmic.

It must be checked that the DALI controller does not overwrite or reset this setting.

The linear dimming curve is specified in the DALI 207 standard. This is an extension to the basic DALI 102 standard and adds LED specific commands. The linear dimming curve is supported in all our DALi & SR LED drivers.

11.3.14 Auxiliary Power Supply Voltage

Product group

LED

11.3.14.1 Description

Use this feature to configure the Auxiliary Power Supply feature in the device.

11.3.14.2 Usage

Select the **Output voltage** box to define the desired output voltage for the auxiliary supply.

11.3.15 Coded Light On and Off

Product group

LED

11.3.15.1 Description

Use this feature to enable/disable the Coded Light feature in the device.

11.3.15.2 Usage

Select the **Enable** check box to use this feature.

11.3.18 Constant Light Output

Product group

LED

11.3.18.2 LED version

The Constant Light Output feature for LED devices will show the following window:



When a newer version of CLO is present in the device, the following window will be displayed:



11.3.18.3 Description

The lumen output of a LED module usually decreases over its lifetime. To compensate, a schedule can be created that gradually increases the lamp's power level over time.

11.3.18.4 Usage

Select the **Enable** check box to use this feature. Click the **New** button to create a default schedule or click the **Plus** button to individually add scenes.
When creating a new schedule, in the dialog window that pops up you can either select an empty schedule, a default schedule or a custom schedule.





When selecting a custom schedule, you have to enter a number of parameters that will define the CLO schedule. These are:

- **Maximum working hours**: the largest number of working hours for which the CLO schedule is defined. This corresponds to the maximum value of the horizontal axis in the resulting CLO graph.
- **Number of scenes**: the number of scenes (bars in the graph, or in the newer version the points in the graph) into which the total number of burning hours is divided
- **Initial power level**: the power level that is the starting point at 0 burning hours
- **Final power level**: the power level at the end of the defined lifetime (the value given for maximum number of burning hours)

After clicking **Finish** a CLO schedule will be created using linear interpolation of the provided values.

Drag the points or the lines in the resulting graph to adjust the configuration. Alternatively, use the table to enter values directly. Single or multiple table rows can be removed by clicking the **Minus** button.

Note! The reliable use of Constant Light Output requires extensive LED specification assessment of life time behavior of LEDs.

11.3.18.5 LED version (simplified)

The simplified Constant Light Output feature will show the following window:



11.3.18.6 Description

The lumen output of a LED module usually decreases over its lifetime. To compensate, a schedule can be created that gradually increases the lamp's power level over time. By configuring the **Maximum working hours** and the **Initial power level** a linear schedule is defined which consists of 16 scenes. The first scene starts at 0h and at the specified initial power level. The last scene starts at the specified working hours and at 100% power level.

11.3.18.7 Usage

Select the **Enable** check box to use this feature. Use the **Maximum working hours** slider to configure the moment in time where the LED module will use the final power level.

Use the **Initial power level** slider to configure at which power level the LED module will initially start.

Note! The reliable use of Constant Light Output requires extensive LED specification assessment of life time behavior of LEDs.

TBD

TBD

TBD

TBD

11.3.22 Corridor Mode

Product group

LED



11.3.22.1 Description

Corridor Mode feature depends on Touch and Dim feature. The Corridor Mode feature adjusts the light to a defined level when a presence sensor detects a person. Corridor Mode can only be activated when the device is in Touch and Dim mode.

11.3.22.2 Usage

Select the **Enable** check box to use this feature. It is not possible to activate the driver via Touch and Dim, when this check box is not selected.

This feature has the following parameters:

- **Normal level**: Light level to be set when presence sensor detects activity

- **Background level**: Low light level to be set when no presence is detected after the fade time
- **Delay time**: The time from the moment the sensor has switched off and the moment the device will start to fade to background level
- **Fade time**: The time used to fade from normal level to background level
- **Prolong time**: When reaching background level, the time after which the device will be switched off
- **Activation time**: The time during which a mains signal must be detected, before the device will switch to Corridor Mode

Alternatively to using the sliders, some lines and points in the graph can be dragged to adjust the configuration.

11.3.23 DALI 102

Product group

LED



11.3.23.1 Description

Use the DALI 102 feature to configure DALI settings via **Device features** tab instead of **Commands tab**.

11.3.23.2 Usage

This feature has the following parameters:

- **Power on level**: Light level applied when driver is powered and DALI supply is connected, when **do nothing** is selected, the driver will not act upon power on.
- **System failure level**: Light level applied when driver is powered and no DALI supply is connected, when **do nothing** is selected, the driver will not act upon system failure
- **Min level**: Minimum light level of the driver, this cannot be set lower than the physical minimum level of the driver and cannot be set higher than the **Max level**
- **Max level**: Maximum light level of the driver, this cannot be set lower than the

11.3.23.3 Min level

- **Fade rate**: Number of fade steps
- **Fade time**: This is used to indicate how long it takes to perform fade
- **Extended fade time base**: Used to calculate extended fade time
- **Extended fade time multiplier**: Used to calculate extended fade time
- **Operating mode**: Operating mode of the driver
- **Short address**: Short address of the driver
- **Scenes**: A configurable preset level for the driver, a driver contains 16 scenes for which can be configured individually
- **Groups**: Defines in which groups the driver is located



Channel 2 :

Power on level: 254 DefaultUnit ☐ Do nothing

System failure level: 253 DefaultUnit ☐ Do nothing

Min level: 170 DefaultUnit

Max level: 254 DefaultUnit

Fade rate: 7

Fade time: 0

Extended fade time base: 0

Extended fade time multiplier: 0

Operating mode: 128 *Operating mode can either be 0 or between 128 and 255

Short address: 255 *Short address can either be 255 or between 0 and 63

Scenes

Scene 0:	255	Scene 4:	255	Scene 8:	255	Scene 12:	255
Scene 1:	255	Scene 5:	255	Scene 9:	255	Scene 13:	255
Scene 2:	255	Scene 6:	255	Scene 10:	255	Scene 14:	255
Scene 3:	255	Scene 7:	255	Scene 11:	255	Scene 15:	255

Groups

☐ Group 0	☐ Group 4	☐ Group 8	☐ Group 12
☐ Group 1	☐ Group 5	☐ Group 9	☐ Group 13

11.3.25 DALI 202

Product group

LED



11.3.25.1 Description

Use the DALI 202 feature to configure DALI settings via **Device features** tab instead of **Commands tab**.

11.3.25.2 Usage

This feature has the following parameters:

- **Emergency level**: Arc power level during emergency, when **do nothing** is selected, the driver will not act upon emergency level
- **Prolong time**: Duration of extended emergency mode
- **Function test interval**: Interval between function tests
- **Duration test interval**: Interval between duration tests
- **Test execution timeout**: Timeout for a pending function or duration test
- **Lamp emergency time**: Accumulated lamp on time while powered by battery
- **Lamp total operation time**: Accumulated lamp on time

TBD

11.3.28 DALI Power Supply

Product group

LED

☒ Enable

11.3.28.1 Description

Use the DALI Power Supply (DALI PSU) feature to enable the device so it will deliver the power supply for DALI communication by itself.

11.3.28.2 Usage

Select the **Enable** check box to use this feature.

11.3.29 Daylight override / Daylight switching

Product group

CONTROL

☐ Enable daylight dependent override

☐ Enable daylight dependent switching

11.3.29.1 Description

Use the DLO/DLS feature to configure the daylight dependent settings for the device.

11.3.29.2 Usage

This feature has the following parameters:

- **Enable daylight dependent override**: When the **Enable daylight dependent override** check box is selected, the lights remain off in case occupancy is detected.
- **Enable daylight dependent switching**: Select the **Enable daylight dependent switching** check box to switch the light off in case sufficient daylight is available.

11.3.30 DC Emergency

Product group

LED



11.3.30.1 Description

This feature is used together with a DC central battery system. The device will dim to a specific level, as soon as a DC voltage is detected at the mains input instead of an AC voltage on the mains input of the device. The dimming of the lamps can either be enabled or disabled during this DC Emergency operation.

11.3.30.2 Usage

Select the **Enable** check box to use this feature. Use the slider or the text field to select a value. The value represents the arc power level when in DC Emergency mode (the label on the right gives the approximate light level percentage). Select the **Allow dimming** check box to allow dimming when in DC Emergency mode.

11.3.31 Device Info

Product group

LED



11.3.31.1 Description

Use the Device Info feature to get or set the device information which may be luminaire specific.

11.3.31.2 Usage

Select the Device Info feature tab to read or write the device information.

11.3.32 DiiA specification DALI Part 253 - Luminaire Maintenance

Product group

CONTROL



11.3.32.1 Description

This feature provides an interface for storing information to enable predictive maintenance of a device.

11.3.32.2 Usage

This feature has the following parameters:

- **Rated median useful life of luminaire:** Use the slider or the text field to select a value. The specified value represents the rated median useful lifetime of the luminaire in hours.
- **Internal control gear reference temperature:** Use the slider or the text field to select a value. The specified value represents the internal control gear reference temperature in degrees Celsius.
- **Rated median useful light source starts:** Use the slider or the text field to select a value. The specified value represents the rated median useful light source starts of the luminaire.

11.3.33 Dimming Interface

Product group

LED

11.3.33.1 Description

Use the Dimming Interface feature to select the dimming interface for the device. The actual options are depending on the device model:

1-10 V
DALI
Dynadimmer
No dimming
AmpDim
LineSwitch
Coded Mains

When **DALI** has been selected, an additional setting appears with which the dimming behavior can be set. Options are **Logarithmic** and **Linear** dimming curves.

11.3.33.2 Usage

Use Dimming Interface to select the desired dimming interface.

11.3.33.3 Product group

FLUO, LED

11.3.33.4 Description

Use the Dimming Interface feature to select the dimming interface for the device.

11.3.33.5 Usage

The available dimming interfaces are stored in the device and therefore need to be read out. When the interfaces are found it will be possible to select **Automatic selection** (enable all interfaces), **No dimming** (disable all interfaces) or a **single** interface.

11.3.33.6 Product group

LED



11.3.33.7 Description

Use the Dimming Interface feature to enable dimming interfaces for the device.

11.3.33.8 Usage

The available dimming interfaces are stored in the device and therefore need to be read out. When the interfaces are found it will be possible to select and enable the main interface. Some interfaces have the possibility to be overridden by another

interface. If that's the case the **Can be overridden by** part will show the other possible interfaces that can be enabled together with the main dimming interface.

Note! All selected interfaces (both the main interface and the selected **Can be overridden by** interfaces) will have their **Enable** value set to true if present. Else the value is set to false.

Note! The **Override** for the **main interface** is automatically set to true if any **Can be overridden by** interface is selected. Else the value is set to false. The **Override** value for all other interfaces (if present) are set to false even if the main interface does not support any **Can be overridden by** interfaces.

11.3.34 Driver addressing

Product group

LED

11.3.34.1 Description

Use the Driver addressing feature to determine the DMX settings for the device.

11.3.34.2 Usage

- **DMX address:** DMX address
- **Enable:** When the check box is cleared the grouping feature within one DMX address is not used.
- **Group size:** Number of devices that operate within one group, all responding to the same DMX address.
- **Group address:** Device number within the group of devices that respond to the same address.
- **DMX Personality**: RDM Personality.

11.3.35 Driver Temperature Limit

Product group

LED



11.3.35.1 Description

Use the Driver Temperature Limit feature to determine the temperature protection settings for the device.

11.3.35.2 Usage

Select the **Enable** check box to use this feature. Use the sliders to changes the values for this feature.

- **Enable:** Select the **Enable** check box to use this feature.
- **Start dim:** Set the temperature at which dimming start.

- **Stop dim:** Set the temperature at which the dimming stops.
- **Shut down:** Set the temperature at which the dim level will be set to zero. When selecting the N/A checkbox, the shutdown temperature is not applied
- **Dim level:** Set the dim level for the Stop dim temperature.

11.3.36 Driver Temperature Limit for Lock

Product group

LED



Driver Temperature Limit Lock



Driver Temperature Limit Unlock

11.3.36.1 Description

The driver supports this feature, must be locked in shut-down state after the thermal limit of the product has been reached.

11.3.36.2 Usage

Next to the regular DTL screen there is a separate tab for the lock feature. Select the **Enable** check box to use this feature.

- **Enable:** Select **Enable** to Enable/disable lock driver feature.
- **DTL Lock Driver:** Feature to lock the driver when lamp is shut down due to too high temperature.
- **DTL Unlock Driver:** Feature to unlock the driver by maintenance service if it was locked.

11.3.37 Dwell Time

Product group CONTROL



11.3.37.1 Description

Use the Dwell Time feature to postpone present detection for a certain time.

11.3.37.2 Usage

This feature has the following parameters:

- **Activated:** Select the **Activated** check box to activate the feature.
- **Enabled:** Select the **Enabled** check box to turn Dwell Time on.

11.3.38 Dynadimmer

Product group

LED



11.3.38.1 Description

Use Dynadimmer to create a dynamic dimming schedule over a period of time.

11.3.38.2 Usage

Select the **Enable*** check box to use this feature. This feature has a number of options, depending on the device model:

- **Time based**: switch between absolute and relative time schedules. When the **Time based** check box is cleared, the Dynadimmer schedule will use its automatically learned midnight point as a reference for timekeeping. When the **Time based** check box is selected, the reference point is the moment when the mains are switched on. Selecting the **Time based** check box changes the graph and removes its dotted midnight line. Note that not all devices support Time based Dynadimmer.
- **Midnight shift**: the midnight point depends on the geographical location. Enter the midnight shift in minutes or use the midnight shift calculation window to automatically adjust the midnight point by the specified offset. Use the calculation button to either manually provide latitude and longitude coordinates or to choose a predefined location. The midnight shift option is unavailable when the **Time based** check box has been selected.

The midnight shift calculation dialog window looks as follows:



- **Latitude**: the latitude of the location in degrees, minutes and seconds. The value that represents the degrees cannot be negative.
- **N-S:** the direction for latitude of the location. The user can either select North or South value.
- **Longitude**: the longitude of the location in degrees, minutes and seconds. The value that represents the degrees cannot be negative.
- **E-W:** the direction for longitude of the location. The user can either select East or West value.
- **Time zone**: the time zone of the location. For GMT+1 enter 1, for GMT-1 enter -1, and so on.
- **Daylight saving**: indication whether daylight saving should be dealt with or not.

Click **OK** to save result of your calculation as the new midnight shift. Note that clicking **OK** is not directly saving your data to the driver. To save midnight shift to a driver you will have to write the whole feature.

Click the **New** button to create a default schedule or click the **Plus** button to add scenes individually. Drag the points or the lines in the graph to create the desired configuration. Alternatively, use the table to enter values directly. Remove single or multiple table rows by clicking the **Minus** button.

Note! The device will follow the dimming schedule. When the output level in the dimming schedule is below the physical min level of the selected lamp, the physical min level will be used. However, some devices are also capable to switch off during the dimming schedule, if a scene was configured at 0 %.
The physical min level of the selected lamp is indicated by the gray-dotted line in the graph.

Note! This feature can contain the **override** check box in some cases. If the check box is selected, that means the dim level can be overridden by other dimming interfaces.

* **Note!** If the device supports interface selection then this feature can only be enabled through the interface selection and the enable will not be shown here.

11.3.38.3 Physical min level

In order to see the correct physical min level of a lamp after Lamp Selection do not forget to switch the driver off for a few seconds. After switching it on again the selected lamp is activated. To see the physical min level of the selected lamp in the graph, click **Read** on the toolbar.

11.3.38.4 Location or custom location

For some device models, only the midnight point offset is stored in the device and **NOT** the (custom) location. In those cases the location information and the custom location is only used to calculate the midnight point offset. After reading out the device, software tries to match the midnight point offset with a location. In case the midnight point offset does not match to a location or the midnight point offset matches multiple locations, software will show “No location”.

For a technical description of the characteristics of the device model, like constraints and limitations, please refer to **Device-specific technical description**.

TBD

TBD

TBD

TBD

11.3.41 End Of Life indication

Product group

LED



11.3.41.1 Description

Use this feature to warn the user at the end of the guaranteed lifespan of the LED module. Once the end of guaranteed life is reached, the device will flash the lamp for 5 seconds and then continue normal operation. LED flashing will happen every time at startup once the device's working hours have exceeded the number of hours specified as End Of Life. This feature uses the same burning hours counter as the Light Source Operating Hours and Constant Light Output features.

11.3.41.2 Usage

Select the **Enable** check box to use this feature. Use the slider or the text field to select a value. The value represents the guaranteed lifetime in hours.

TBD

TBD

TBD

TBD

TBD

TBD

TBD

11.3.50 Light Source Operating Hours

Product group

LED

11.3.50.1 Description

Use this feature to manually set or reset the number of operating hours for the LED module. This is useful when replacing the LED module, thereby resetting features like Constant Light Output and End Of Life indication.

11.3.50.2 Usage

Use the slider or the text field to select a value. The value represents the number of operating hours.

11.3.51 LineSwitch

Product group

LED



11.3.51.1 Description

This feature provides an interface for easy dimming via pilot-line or external sensor (presence) of a group of lamps. Dimming to desired level can be controlled by

applying a 230V between the DALI inputs. The fade times can also be set using the fade on-, fade off and switch off delay time.

11.3.51.2 Usage

Select the **Enable*** check box to use this feature. This feature has the following parameters:

- **High V level**: Use the slider or the text field to select a value. The value represents the light level to be set when high voltage is detected on themains.
- **Low V level**: Use the slider or the text field to select a value. The value represents light level to be set when low voltage is detected on themains.
- **Fade up time**: Use the slider or the text field to select a value. The value represents the fade on time to be used.
- **Switch off delay time**: Use the slider or the text field to select a value. The value represents the switch off delay time to be used.
- **Fade down time**: Use the slider or the text field to select a value. The value represents the fade off time to be used.

In case the device supports Level 2 settings, these will be visible on the UI. Select the **Enabled Level 2**** check box to use the second dim level function. This option has the following parameters:

- **Delay for Level 2**: Use the slider or the text field to select a value. The value represents the delay time to be used in activation of the second dimlevel.
- **Level 2**: Use the slider or the text field to select a value. The value represents the light level to be set when the second dim level is active.

When the [Switch Off delay time] is programmed in combination with the second level, the dim level during the switch off delay is the active level (depending on the polarity this is [High V level] or [Low V level]). The [Delay for Level 2] will start after the [Switch Off delay time] has expired.

* **Note!** If the device supports interface selection then this feature can only be enabled through the interface selection and the enable will not be shownhere.

** **Note!** When the LineSwitch function is disabled, the enabled second level function is implicitly also not effective. The second level uses the same fade up and fade down times as the High V and Low V levels.

11.3.52 Load Fault Indicator Thresholds

Product group

CONTROL



11.3.52.1 Description

To allow the SR Bridge to set the DALI lamp failure detection properly, the SR Bridge must be configurable to set a power limit that corresponds to the lamp failure level. This involves setting the correct maximum power of all downstream drivers combined and the minimum detection dimlevel for which the SR Bridge will not update the lamp failure status.

11.3.52.2 Usage

This feature has the following parameters:

- **Lamp failure power level:** Use the slider or the text field to select a value. This value corresponds to the maximum power of all downstream drivers combined.

- **Minimum Driver Dim Level**: Use the slider or text field to select a value. This value corresponds to the minimum detection dimlevel for which the SR Bridge will not update the lamp failure status.

TBD

11.3.54 Luminaire (Fixture) Information

Product group

LED

Content format ID:	Unformatted content	
GTIN (EAN13):	9999999999999	
Identification number:	18446744073709551615	☐ Use device UID
Additional info (101):	Some extra information	

11.3.54.1 Description

Luminaire info has 4 possibilities. It is recommended to use “unformatted” or v3 (DALI part 251). The other formats are predecessors and/or customer specific formats.

Luminaire (Fixture) Information contains three mandatory fields: the **Content format ID** to select the content format, the **GTIN** and the **Identification number** of the luminaire which are used as traceability information for OEMs.

Depending on the selected **Content format ID**, additional fields are available for storing more detailed information. For example, when selecting ‘Unformatted content’ as **Content format ID**, the **Additional info** field can be used for additional control gear information.

11.3.54.2 Usage

- **Content format ID:** Select the format in which to store the information. Additional fields to fill are shown on the UI (or in some cases only their maximum allowed length change) when changing the **Content format ID.**
- **GTIN:** Use the textbox to change the value. The **GTIN** always contains 13 digits: if the value given by the user is less than 13 digits, leading 0s will be added till the number reach 13 digits.
- **Identification number:** Use the textbox to change the value. The **Identification number** can have up till 15 digits, however, the value given by the user shall not exceed the value shown above in the picture.
- Select **Use device UID** checkbox to enable copy identification number at power-on. If the checkbox is enabled, the field **Identification number** is not editable.

Additional fields are available for storing more detailed information.

Note! If the field **Use device UID** is changed, the user will need restart the device.

TBD

11.3.57 Min Dim Level

Product group

LED

11.3.57.1 Description

This feature provides an interface for setting the min dim level of a device.

11.3.57.2 Usage

Select the **Enable** check box to use this feature. Use the slider or the text field to select a value. The value represents the min dim level in percentage.

TBD

11.3.59 Module Temperature Protection

Product group

LED



11.3.59.1 Description

Use this feature to regulate lamp power when the LED module gets too hot. At a certain temperature the lamp starts to dim in order to control temperature. At a critical temperature level the lamp will switch off completely.

11.3.59.2 Usage

Select the **Enable** check box to use this feature. Drag the points or the lines in the resulting graph to adjust the configuration. Alternatively, use the sliders to changes values directly. Based on the device model, the feature is shown in either temperature (degrees Celsius) or resistance values (in Ohm).

Note! For a detailed technical description of the characteristics of the device model, like constraints and limitations, please refer to **Device-specific technical description**.

11.3.61 NTC on LEDset

Product group

LED



11.3.61.1 Description

Use this feature to regulate lamp power when the LED module gets too hot. At a certain temperature the lamp starts to dim in order to control temperature. Configure the resistance values to determine the dimming behavior.

11.3.61.2 Usage

Select the **Enable** check box to use this feature. Drag the points or the lines in the resulting graph to adjust the configuration. Alternatively, use the sliders to changes values directly.

Note! For a detailed technical description of the characteristics of the device model, like constraints and limitations, please refer to **Device-specific technical description**.

TBD

TBD

11.3.64 OEM Write Protection

Product group

LED

11.3.64.1 Description

OEM Write Protection (OWP) defines a password that will be set in the driver so the data of OEM Write-protected features can only be written to the driver by providing the configured password.

11.3.64.2 Usage

When one or more of the **OEM Write Protected features** check boxes are selected, a password needs to be entered. This password must contain 4 numbers between 0 and 255. Passwords containing 0-0-0-0 and 255-255-255-255 are not allowed. The password needs to be verified before it can be stored in the driver. Once a password is configured into the device, it is necessary to provide the current password when writing other features that are OEM Write-protected. These features are indicated by a padlock icon in the **Write** screen.

When the OWP feature is read, only the values of the feature check boxes are shown on-screen, so it is not possible to retrieve the currently configured password.

TBD

TBD

TBD

11.3.70 SR Power Supply

Product group

LED

- [x] Enable
- [ ] High range current
- [ ] Auto disable
- [ ] Heartbeat
- [ ] Last gasp

11.3.70.1 Description

Use the SR Power Supply (SR PSU) feature to enable the device so it will deliver the power supply for DALI communication by itself.

11.3.70.2 Usage

Select the **Enable** check box to use this feature.
Select the **High range current** check box to enable the high range current functionality.
Select the **Auto disable** check box to enable the auto disable functionality. Select the **Heartbeat** check box to enable the heartbeat functionality.
Select the **Last gasp** check box to enable the last gasp functionality.

11.3.71 Step Dimming

Product group

LED



11.3.71.1 Description

Step dimming is the basic dimming requirement for energy efficiency.

11.3.71.2 Usage

Select the **Enable** check box to use this feature. Select Bi-level radio button to edit Bi active dim level. Select Tri-level radio button to edit Tri line dim levels.

11.4 Using the features summary

For most devices an additional tab is shown on the **Device features** tab, called **Summary**. The **Summary** tab gives a compact overview of the settings that have been entered for all the features of this device. As the features are different per product group, the summary is also different. The features cannot be changed on the **Summary** tab.



11.5 Saving and opening a feature configuration file

To save and open a feature configuration file, the **Device features** tab must be active.

Feature configurations can be saved to a file for later use. To do so, first select the **Device features** tab to make feature configurations for the selected device. Then, click the disk icon on the toolbar or select **File** ⍰ **Save as**.



A dialog window pops up that lists the features of the device:



Select any number of features and click **Save**. The save file dialog window appears. Choose a location and a file name and click **Save**. The selected features will now be written to the file.

It is also possible to save the device information alongside the features. This data can later be used in TCI Workflow to ensure the configuration can only be configured in the saved device model.

As mentioned before, some features can be OEM Write-protected. These features will be marked with a padlock icon in the dialog.



In this case it is possible to save the current password alongside the features, so TCI Workflow can use this password to be able to write the data of the features that are OEM Write-protected to the driver.

When using NFC, TCI compares the provided password with the password in the device before writing the new data. When there is a mismatch, an error message will be shown.



When using DALI, it is also possible to save DALI settings along with the feature configuration. This can be done by checking the **Include DALI settings in a separate file**.



Note that this feature can be enabled or disabled from **Preferences**.

To open a feature configuration file, click the folder icon on the toolbar or select **File** ⍰ **Open**. The open file dialog window appears. Select a file and click **Open**.



The contents of the **Device features** tab are updated to show the information that was read from the file.

Only feature configurations are stored in the file. This means that a file made for a certain device can be read into the **Device features** tab for a different device.
TCI attempts to read as many feature configurations as possible.

Example: a feature configuration file exists that was made for device D1, which has features AOC, CLO and MTP. A different device, D2, has features AOC and Touch and Dim. When opening the feature configuration file for device D1 while device D2 is selected, only the configuration for feature AOC will be read, since features CLO and MTP are not supported by device D2.

Feature configuration files can be distributed to other users of software. This user then opens the file and configures the connected device.

11.6 Configuring a single device

There are situations in which only one device will be configured at the time. In this case it is not necessary to have the full functionality of the **Network**, including **Scan** and **Commission** buttons. To optimize the workflow for single device configuration, select **Single device programming** in the **Application Mode Selector**.

When **Single device programming** has been selected, software will automatically scan the DALI network and select the connected device for communication. In this mode, the **Network** panel is collapsed by default. If multiple devices have been found, software will show a message and switch to regular configuring mode.

11.7 Configuring multiple DALI devices (simultaneously)

There are situations in which multiple devices need to be configured at the same time. The procedure to simultaneously configure multiple devices of the SAME TYPE AND VERSION is as follows:

1. Connect maximum 64 devices of the SAME TYPE AND VERSION, in parallel to the DALI connectors of the USB2DALI interface
2. Connect the USB2DALI interface to the USB port (both black and red USB plugs (USB-A)).
3. Connect the devices to the mains.
4. Start software
5. Choose **Tools・Preferences**
6. Clear the **Write & verify** check box and click **OK**
7. Click the **Commission** button on the **Network** panel to start commissioning.
8. Choose **Actions・Add virtual device**.
9. Select the device of the same type and version as the ones connected on the **Network** panel.
10. Select the **Device features** tab
11. Change any of the features.
12. Click **Write** on the toolbar.

Note! There will not be an individual confirmation for every device. So if any of them failed to be configured, it is not known which one.

Note! Remember that applications can be affected by the availability of the short address.

11.8 Configuring multiple DALI devices (consecutively)

There are situations in which multiple devices need to be configured one after another. The procedure to consecutively configure multiple devices of the SAME TYPE AND VERSION should follow the next steps.

11.8.1 Software

1. Connect one device
2. Connect the USB2DALI interface to the USB port (both black and red USB plugs (USB-A))
3. Connect the device to the mains
4. Start software
5. If needed, select **All** in the **Application mode selector**
6. Click **Scan network** in the **Network** panel to start scanning
7. Select **File・Open** to open the required feature configuration file
8. Right click the device in the **Network** panel and select **Reset short address**
9. Select the **Device features** tab
10. Click **Write** on the toolbar
11. Replace device
12. Click **Write** on the toolbar
13. Replace device
14. Etc.

Note! Remember that applications can be affected by the removal of the short address.

11.10 Offline feature configuration preparation

When a device or network is not present, it is still possible to prepare a feature configuration. This might be useful when you would like to prepare a feature configuration file that can be read at a later time, and written to the device when it is connected. To make a configuration you need to add one or more virtual devices.

To add a virtual device, right-click **All devices** in the **Network** and choose **Add virtual device**.
Alternatively choose **Actions・Add virtual device**.



A dialog window pops up that lists all devices supported by software.



Make a selection and click **OK**. An item called **Virtual devices** appears in the **Network**. Expand it by clicking the **+** sign to see the list of virtual devices. Note that virtual devices do not have a short address and software will show **Broadcast** on the location of the short address. Virtual devices can only be addressed using broadcast commands.

Select a virtual device and select the **Device features** tab. The device features are shown as if the device was physically connected. Configure the features as desired, and then save the feature configuration to a file. You have now made a feature configuration file without being connected a device.

11.11 Sending DALI commands

To manually send DALI commands select the **Commands** tab.

The **Commands** tab contains the following tabs:

- 102 tab
- 202 tab

The **102** tab has the following specific pane:

- Light control



11.11.1.1 Light control

This pane offers a number of buttons to immediately influence the behavior of the device. These controls are useful when quick feedback in terms of light is desired. Selecting the **Synchronize actual level** check box will reflect the actual light level in the slider after each command.

The **202** tab has the following specific pane:

- Control Device



11.11.1.2 Control Device

This pane gives direct access to emergency controls that immediately influence the behavior of the emergency device. These controls allow users to get quick feedback in terms of the behavior of an emergency device in different situations.

Both tabs contain the following panes:

- Commander
- Configuration commands

11.11.1.3 Commander

To send a DALI command as a broadcast command, first select **All devices** in the **Network**, then select the DALI command in the **Commander** pane and finally click the **Send** button. To send a DALI command to a specific address or group, select the corresponding device or group in the **Network**.

Note! DALI Ed2 commands are marked by an asterisk (*).

11.11.1.4 Configuration commands

Both tabs contain this pane. However, the content of this pane is different for each tab. To manually set or get the so-called DTR (Data Transfer Register) values of the device, use the buttons in the left part of this pane.

To use the actual DTR value of the device with a number of DALI commands, go to 102 tab to use the buttons in the right part of this pane. Besides a number of DALI commands using the DTR value, other DALI102 commands such as **Reset**, **Step Up** and **Step Down** are directly available.

To configure values like **Prolong Time**, **Function Test Interval**, **Duration Test Interval**, **Test Delay Time High**, **Test Delay Time Low** and **Test Execution Timeout**

that are needed while using emergency commands, go to 202 tab to use the sliders or text fields in the right part of this pane to modify their values. The allowed range for those values is between 0 and 255.

11.12 Traceability

The Traceability tab summarizes how many times the configuration of the device was changed, when the last configuration change happened using unknown software and a pane showing details of the first, second and last configuration change (if present).



Every entry in the list shows the date of the configuration change, which software version was used and which type of interface was used at the time of the configuration change.

11.13 Working with DALI command scripts

To run a series of DALI commands, a script can be created in the **Scheduler** tab. This script can be executed any number of times. Furthermore it is possible to save the script to a file for easy reuse.



The **Scheduler** tab has the following panes:

- Add item

  - A **CMD** button to insert DALI commands
  - A **FOR** button to insert a loop, consisting of a FOR and an END FOR
- Selected, containing buttons to work with (**Up**, **Down**, **Delete, Clear All**) the currently selected item in the schedule
- Items, representing the schedule
- Selected item, the settings of the currently selected item
- Schedule playback buttons (**Play**, **Pause**, **Stop**)

To add a command to the schedule, click the **CMD** button. The command is added to the schedule and it is automatically highlighted. On the **Selected item** pane, choose the desired DALI command and settings. By selecting the **Start time** check box and providing a time, this command will be sent at an exact moment in time.
Alternatively, commands can be sent relative to each other. Select the **Delay** check box and provide a value in milliseconds to do so. At **Device address** you can select to which device to send this command. You can choose between the currently selected device, a broadcast or one of the 64 available short addresses (0-63). Then, select which DALI command will be sent by using the two drop down boxes; the first selects the command group and the second selects the actual command. If a command parameter is required, enter it into the **Data** field.

Note! DALI Ed2 commands are marked by an asterix(*).

By repeatedly clicking the **CMD** button, a series of DALI commands can be created. Each command has its own settings.

A schedule can also contain loops. A loop has a FOR-item, one or more commands, and finally an END FOR-item to mark the end of the loop. Click the **FOR** button to create a loop. By default, the loop will run infinitely (that is, until schedule playback is manually stopped or paused by clicking **Stop** or **Pause**). To change the number of times the loop will be executed, select the FOR-item and enter a value for **Maximum count** on the **Selected item** pane.

To rearrange the schedule, select a command and use the **Up** and **Down** buttons to move this up or down respectively. Delete a command by clicking the **Delete** button. To clear all the commands use **Clear All** button.

To start, pause, or stop a schedule playback, use the **Play**, **Pause** and **Stop** buttons. If the command is a query, the return data of the executed command will be displayed.

To save a schedule to file for later use, click the disk icon on the toolbar. Alternatively, select **File** ▯ **Save** or **File** ▯ **Save As**. Choose a location, a filename and click **Save**.
The schedule has now been saved.

To open a previously stored schedule, click the folder icon on the toolbar.



Alternatively, select **File** ⇨ **Open**. Choose a schedule file and click **Open**. The **Scheduler** tab now shows the schedule from the file.

11.14 Querying devices

To automatically execute a number of standard DALI query commands select the **Query** tab.



To make sure that the information in the **Query** tab corresponds to the selected device, click **Read** on the toolbar.



11.15 Accessing Diagnostics

You can configure all diagnostics features that are supported by a specific device. For a device selected in the **Network**, the **Diagnostics** tab displays the set of diagnostics features that corresponds to this device. Upon selecting another device, the **Diagnostics** tab will be updated as well. This mechanism ensures that only the features supported by the selected device can be configured.

The **Diagnostics** tab has a panel with a column of tabs on the left-hand side. Each feature has its own tab.



The **Read** and **Write** functionality for **Diagnostics** works the same way as what has been described in chapter 12.3 of this manual.

11.15.1 Diagnostics

Product group

LED and CONTROL

Description

Use this feature to consult the diagnostics values.

Note that some diagnostics might be OEM Readout-protected and require a password before being read out.

TBD

11.15.1.1 Diagnostics for a LED



Single values

Module on time	0 hr(s) 0 min 14 s
System on time	212 hr(s) 7 min 42 s
Driver temperature	25 °C
LED module dim level	0 %
LED module temperature	-27 °C
LED module voltage	214 V
Mains overvoltage count	0
Maximum recorded driver temperature	-273 °C
Maximum recorded LED module temperature	-273 °C
Minimum recorded driver temperature	-273 °C
Minimum recorded LED module temperature	-273 °C
Output current	1 mA
System starts	336
Mains too high	False
Mains too low	False
Module light reduction active	False
Module NTC missing	False
Module temperature too high	False
Open circuit	True
Short circuit	False
Start fade up active	False

Histograms

A brief explanation of all LED diagnostics is given below.

Table 2 LED diagnostics

Diagnostic	Description
LED module voltage (V)	Represents the output LED module voltage.
LED module current (mA)	Represents the output LED module current
LED module dim level (%)	Represents the current dim level set by the LED driver. Takes into account all factors that can influence dimming like Constant Light Output,

	Module Temperature Protection, all dimming interfaces etc.
LED module temperature (ºC)	Represents the LED module temperature. Available only when Module Temperature Protection is selected and an NTC value is selected.
Driver temperature (ºC)	Represents the internal driver temperature. It does not represent T_{case} of the driver. Though there is a correlation between T_{case} and internal driver temperature, the difference can vary depending on current setting of driver.
System starts	Represents the number of times the LED driver is powered ON.
System on time (h)	Represents the hours the LED driver is ON. (LED module is OFF)
Module on time (h)	Represents the number of hours the LED **module** is powered ON.
Module energy consumed	Represents the energy consumed by LED module alone. Only output parameters (LED module voltage and current) are used to calculate energy. The LED driver energy consumption is not accounted. Hence it does **not** represent true **input** energy consumption of the LED system.
Short circuit	This indicates if output LED module is shorted.
Open circuit	This indicates if output LED module is open or not connected to LED driver
Module NTC missing	This indicates missing NTC on the LED module. Available only when Module Temperature Protection is selected and 10k NTC is selected. Missing NTC flag will not be activated if 15k+390 Ω NTC is selected.
Module temperature reduction active	This indicates light level reduction due to module temperature being active.
Module temperature too high	This indicates whether the LED module temperature exceeds 90 ºC causing module to turn OFF.

Mains too low	This indicates that the LED driver is not operating since input voltage at power ON is too low.
Adjustable Startup Time active	This indicates that the LED driver is in the startup phase as defined by the Adjustable Startup Time. For example if the Adjustable Startup Time is set to 20000 ms, and the diagnostic information is read at startup within 20 s, this check box will be selected indicating startup condition.

11.15.1.2 Subset of LED diagnostics

Single values	
Module on time	0 hr(s) 0 min 0 s
System on time	32 hr(s) 15 min 16 s
Driver temperature	21 °C
Fault code 01	0
Fault code 02	0
Fault code 03	0
Fault code 04	0
Fault code 05	0
Fault code 06	0
Fault code 07	0
Fault code 08	0
Fault code 09	0
Fault code 10	0
Lamp on cycles count	0
LED module dim level	0 %
LED module temperature	-273 °C
LED module voltage	0 V
Mains overvoltage count	0
Maximum recorded driver temperature	44 °C
Maximum recorded LED module temperature	-273 °C
Minimum recorded driver temperature	23 °C
Minimum recorded LED module temperature	-2147483648 °C
Output current	0 mA
System starts	8

Table 3 Subset of LED diagnostics

Diagnostic	Description
System on time (h:m:s)	Represents the hours, minutes and seconds the LED driver is ON. (LED module is OFF).
Module on time (h:m:s)	Represents the number of hours, minutes and seconds the LED **module** is powered ON.
System starts	Represents the number of times the LED driver is powered ON.
Maximum recorded driver temperature (°C)	Maximum driver temperature ever reached during the lifetime of the driver.

Minimum recorded driver temperature (°C)	Minimum driver temperature ever reached during the lifetime of the driver.
Maximum recorded LED module temperature (°C)	Maximum module temperature ever reached during the lifetime of the driver.
Minimum recorded LED module temperature (°C)	Minimum module temperature ever reached during the lifetime of the driver.
Mains overvoltage count	Number of times the mains exceeded the maximum allowed mains voltage level.

The table above describes some of the available diagnostic features. Depending on the availability of the different LED subset diagnostic features in a device, more or less diagnostic values will be shown.

11.15.1.5 DiiA specification DALI Part 253 - Diagnostics

Single values	
Control gear operating time	52 hr(s) 48 min 2 s
Control gear start counter	14
Control gear external supply voltage	230,0 Vrms
Control gear external supply voltage frequency	50 Hz
Control gear power factor	Not Available
Control gear overall failure condition	False
Control gear overall failure condition counter	0
Control gear external supply undervoltage	False
Control gear external supply undervoltage counter	0
Control gear external supply overvoltage	False
Control gear external supply overvoltage counter	0
Control gear output power limitation	Not Available
Control gear output power limitation counter	0
Control gear thermal derating	Not Available
Control gear thermal derating counter	0
Control gear thermal shutdown	Not Available
Control gear thermal shutdown counter	0
Control gear temperature	43 °C
Control gear output current percent	0 %
Light source start counter resettable	0
Light source start counter	0
Light source on time resettable	97486 hr(s) 0 min 0 s
Light source on time	0 hr(s) 0 min 0 s
Light source voltage	6553,5 V
Light source current	65,535 A
Light source overall failure condition	True
Light source overall failure condition counter	14
Light source short circuit	Not Available
Light source short circuit counter	0
Light source open circuit	True
Light source open circuit counter	14
Light source thermal derating	Not Available
Light source thermal derating counter	0
Light source thermal shutdown	Not Available
Light source thermal shutdown counter	0
Light source temperature	195 °C

Table 6 DiiA diagnostics

Diagnostic	Description
Control gear operating time (h:m:s)	Represents the operating time of the control gear in hours, minutes and seconds.
Control gear start counter	Represents the amount of times the control gear started.
Control gear external supply voltage (Vrms)	Represents the external supply voltage of the control gear in Vrms.
Control gear external supply voltage frequency (Hz)	Represents the external supply voltage frequency of the control gear in Hz.

Control gear power factor	Represents the power factor of the control gear.
Control gear overall failure condition	Represents the overall failure condition of the control gear.
Control gear overall failure condition counter	Represents the amount of times the control gear overall failure condition occurred.
Control gear external supply undervoltage	Represents the external supply under voltage of the control gear.
Control gear external supply undervoltage counter	Represents the amount of times the control gear external supply undervoltage occurred.
Control gear external supply overvoltage	Represents the external supply overvoltage of the control gear.
Control gear external supply overvoltage counter	Represents the amount of times the control gear external supply overvoltage occurred.
Control gear output power limitation	Represents the output power limitation of the control gear.
Control gear output power limitation counter	Represents the amount of times the control gear output power limitation occurred.
Control gear thermal derating	Represents the thermal rating of the control gear.
Control gear thermal derating counter	Represents the amount of times the control gear thermal derating occurred.
Control gear thermal shutdown	Represents the thermal shutdown of the control gear.
Control gear thermal shutdown counter	Represents the amount of times the control gear thermal shutdown occurred.
Control gear temperature (°C)	Represents the temperature of the control gear in °C.

Control gear output current percent (%)	Represents the output current percentage of the control gear in %.
Light source start counter resettable	Represents the resettable amount of starts of the light source.

Light source start counter	Represents the amount of starts of the light source.
Light source on time resettable (h:m:s)	Represents the resettable light source operating time in hours, minutes and seconds

Light source on time (h:m:s)	Represents the light source operating time in hours, minutes and seconds.
Light source voltage (V)	Represents the light source voltage in V.
Light source current (A)	Represents the light source current in A.
Light source overall failure condition	Represents the overall failure condition of the light source.
Light source overall failure condition counter	Represents the amount of times the light source overall failure condition occurred.
Light source short circuit	Represents the short circuit status of the light source.
Light source short circuit counter	Represents the amount of times the light source short circuit occurred.
Light source open circuit	Represents the open circuit status of the light source.
Light source open circuit counter	Represents the amount of times the light source open circuit occurred.
Light source thermal derating	Represents the thermal rating of the light source.
Light source thermal derating counter	Represents the amount of times the light source thermal derating occurred.
Light source thermal shutdown	Represents the thermal shutdown of the light source.
Light source thermal shutdown counter	Represents the amount of times the light source thermal shutdown occurred.
Light source temperature (°C)	Represents the temperature of the light source in °C

Depending on the availability of the different DiiA diagnostic features in a device, more or less diagnostic values will be shown.

11.15.2 Set Lamp On Time

Product group

LED

11.15.2.1 Description

Use this feature to set the lamp on time or reset the diagnostics values.

11.15.2.2 Usage

Use the slider or the text field to set the **Lamp on time** value.

Select the **Reset module diagnostics** check box to reset the following diagnostics:

- Lamp on time counter
- Maximum and minimum module temperature
- Module Steady state temperature histogram
- Lamp On Cycles

11.16 Accessing Energy Meter

To access energy meter, select a device in the **Network** and select the **Energy Meter** tab. This tab displays the set of energy meter features that correspond to this device to get an indication of the energy consumption of the device. Upon selecting another device, the **Energy Meter** tab will be updated as well. This mechanism ensures that only the features supported by the selected device can be configured.

The **Energy Meter** tab has a panel with a column of tabs on the left-hand side. Each feature has its own tab.



The **Read** functionality for **Energy Meter** works the same way as what has been described in chapter 12.3 of this manual. **Write** functionality is not available for **Energy Meter**.

11.16.1 Energy Meter

Total active energy consumed	89	Wh
Active energy consumed	2177	mWh
Active power	16	dW
Total apparent energy consumed	152	Wh
Apparent energy consumed	3586	mWh
Apparent power	26	dW
Total active energy consumed at load side	0	Wh
Active energy consumed at load side	0	mWh
Active power at load side	0	dW

11.16.2 DiiA specification DALI Part 252 - Energy reporting

Active energy	89	E0 Wh
Active power	16	E-1 W
Apparent energy	152	E0 VAh
Apparent power	26	E-1 VA
Active energy loadside	281474976710655	E0 Wh
Active power loadside	4294967295	E-1 W

Depending on the availability of the different DiiA Energy Meter features in a device, more or less energy meter values will be shown.

11.17 Accessing Installer

You can configure all installer features that are supported by a specific device. For a device selected in the **Network**, the **Installer** tab displays the set of installer features that corresponds to this device. Upon selecting another device, the **Installer** tab will be updated as well. This mechanism ensures that only the features supported by the selected device can be configured.

The **Installer** tab has a panel with a column of tabs on the left-hand side. Each feature has its own tab.



11.17.1 Coded Light Randomize

Product group

LED

11.17.1.1 Description

Use this feature to create a random id for coded light data.

11.17.1.2 Usage

When the **Randomize** flag is enabled, the device will generate a new random id, write this id into coded light data and clear the flag.

11.18 Working with the DALI Sniffer



- **Start Sniffing/Stop Sniffing:** When clicked, starts/stops the actual sniffing
- **Auto scroll:** When checked the result window automatically scrolls to the latest entry.
- **Auto save:** Automatically save the sniffing results to the selected file
- **Browse…:** Select file to store sniffing results.

To save the result to a file that is not the auto save file, click on the save button in the menu bar.



An example:

Timestamp	Time Delta Between Frames(us)	Answer	Data	Address	Command ID	Command	Error
6/12/2015 09:48:53.4	0	Write	0x0590	SHORT_2	Cmd_144	QUERY_STATUS	
6/12/2015 09:48:53.4	20820	Read	0x82	-	-	130	
6/12/2015 09:48:53.5	32550	Write	0x0591	SHORT_2	Cmd_145	QUERY_CONTROL_G...	
6/12/2015 09:48:53.5	20460	Read	0xFF	-	-	255	
6/12/2015 09:48:53.5	29140	Write	0x0592	SHORT_2	Cmd_146	QUERY_LAMP_FAILU...	
6/12/2015 09:48:53.5	20890	Read	0xFF	-	-	255	
6/12/2015 09:48:53.6	32090	Write	0x0593	SHORT_2	Cmd_147	QUERY_LAMP_POW...	
6/12/2015 09:48:53.6	34490	Write	0x0594	SHORT_2	Cmd_148	QUERY_LIMIT_ERROR	
6/12/2015 09:48:53.6	36490	Write	0x0595	SHORT_2	Cmd_149	QUERY_RESET_STA...	
6/12/2015 09:48:53.7	55260	Write	0x0597	SHORT_2	Cmd_151	QUERY_VERSION_N...	
6/12/2015 09:48:53.7	20480	Read	0x08	-	-	8	
6/12/2015 09:48:53.8	27870	Write	0x05FF	SHORT_2	Cmd_255	QUERY_EXTENDED_...	
6/12/2015 09:48:53.8	35940	Write	0x0598	SHORT_2	Cmd_152	QUERY_CONTENT_D...	
6/12/2015 09:48:53.8	20910	Read	0x12	-	-	18	
6/12/2015 09:48:53.8	34080	Write	0x059C	SHORT_2	Cmd_156	QUERY_CONTENT_D...	

Column 1 - Timestamp:	The time stamp of the message
Column 2 - Time delta between Frames (us)	The time difference in microseconds between two consecutive commands
Column 3 - Answer	The answer type, either an read or write message
Column 4 - Data	The data being send or received
Column 5 - Command ID	The ID of a command (only if a command is used)
Column 6 - Command	The known DALI command name, if no command then decimal value of the received Data
Column 7 - Error	The kind of error that might have occurred

The color of a line in the sniffer pane indicates the type of the DALI command.

11.18.1 Sniffing with multiple interfaces

It is possible to sniff multiple DALI networks on the same PC. To do this:

- Connect multiple USB2DALI devices to the PC.
- In software go to the Preferences window and select the **Show connection settings on startup** option.
- Start software multiple times and select different interfaces.
- Once all software are started, start in each software the sniffer.

Note! When multiple software connect to the same interface, the sniffing will not work anymore.

TBD

TBD

TBD

11.21 The logging window

The **logging window** shows the communication related to the features currently being read or written or when DALI commands are sent or received through the USB2DALI interface.



11.21.1.1 Timestamp

The time the feature was read or written or the time the command was sent. The format of the timestamp is: <date> <time>.

11.21.1.2 Address

The short address to which the feature or command was sent. In case **Broadcast** is mentioned, all devices are addressed.

11.21.1.3 Description

The name of the feature or the actual DALI command.

11.21.1.4 Result

Result of the communication.

11.22 Setting preferences

Software has a preferences window that allows you to customize the way software works. To access the preferences window select **Tools Preferences**.



The **Preferences** window that pops up allows you to set software preferences.

11.22.1 General preferences



The following list summarizes the available preferences and gives an explanation for each.

- **Show application mode selector on startup**. When software is started you are presented with a screen that allows you choose an application mode, based on the tasks you would like to perform. You can disable this screen by clearing the **Show application mode selector on startup** check box. Changing this settings only takes effect once software is restarted.
- **Scan network automatically on startup**. By selecting this check box software will automatically initiate a network scan on startup. Changing this settings only takes effect once software is restarted.
- **Start maximized on startup**. By selecting this checkbox software will be started full screen. Changing this settings only takes effect once software is restarted.
- **Play sounds when features are configured**. When this check box is selected, software will make a sound when a feature configuration is (un)successfully written to a driver.
- **Play sounds when features, diagnostics or energy meter are read**. When this check box is selected, software will make a sound when a feature configuration is (un)successfully read from a driver, when energy meter or when diagnostics are (un)successfully read from a driver.

- **Prevent sleep mode**. By selecting this check box software will prevent the PC or laptop from automatically entering the sleep mode as long as is active.
- **Write & verify**. By default, software will write parameters to the connected device(s) without checking the state of the device afterwards. By enabling **Write & verify** you force software to perform an additional verification step by reading back the written parameters immediately after writing. If the received values differ from the parameters that were written, software will alert you that there is a deviation between software and the device.
  The **Write & verify** uses different status icons then **Write**. When a **Write & verify** action is successful the icon will be totally green . When the verify action has failed the entire icon will become red. A pending action will be displayed is a grey icon. It is also possible that a part of the **Write & verify** fails. To help indicate where the action failed, two extra icons exist. If the first half of the icon is red and the second part is grey, then the write action failed. When the first part is green and the second part is red, then the read action has failed. It is possible to have both the Write & verify as orange, this means that the feature might not be configured correctly because the program could not verify the result.
- **Show connection settings**. Changing this setting allows you to control the appearance of Connection Settings window when software starts. The following options are possible:
  Only when no interface connected: Connection Settings window will be shown on startup only when there are no interfaces connected.
  Always on startup: Connection Settings window will always be shown on startup.
  Never on startup: Connection Settings window will never be shown on startup.
- **Re-enable all warnings**. Software produces a number of warnings that you can disable by selecting their **Don't show this message again** check box. If you would like to reset all suppressed warnings click the **Re-enable all warnings** button.

11.22.2 DALI



- **DALI scan method**. Changing this setting allows the user to control the way in which a DALI network is scanned. The following options are possible:
  By short address: DALI devices are scanned by their short address.
  By random address: DALI devices are scanned by their random address.
- **Save DALI configuration**. Checking this setting give the users the ability to save DALI settings when saving a feature file. By clearing this check box, the save DALI settings option will not appear when saving a feature file.

For more details on the DALI scan methods, see **Identifying devices**.

11.22.3

TBD

11.23 Manually selecting the USB2DALI interface

Software will automatically detect the USB2DALI interface that is connected to the PC. However when multiple interfaces are connected it will use the interface on the port that is found first. It is possible to manually change the port that is used by selecting **Tools Connection settings.**



In the pop-up window it is then possible to select the desired port.



Notice! The unique id of the interface is shown at the port selection. This, to be able to identify which interface is used by which software instance (when configuring devices in parallel using multiple instances of software).

11.24 Enabling/Disabling the power supply of the USB2DALI interface

The USB2DALI interface will automatically detect if the DALI bus is powered by another device (for example a DALI power supply). If the DALI network is not powered, it will use its internal power supply.



If, during operation, the DALI network is changed in a way that it requires the USB2DALI interface to switch on or off its internal power supply, you can do so using the option **Tools** ⍰ **Power supply**.

11.25 Supported features

The table below gives an overview of all features that are supported by software and to which product groups they apply.

Table 7 Supported features

Device feature	Product group	
	LED	
	Indoor	Outdoor
0-10V / 1-10V (SR bridge)		
0-10V / 1-10V (LED driver)	x	
ActiLume General		
ActiLume Mode		
ActiLume Scene		

Active Cooling	x
Adjustable Light Output	x
Adjustable Output Current	x
Adjustable Output Current Multi-Channel	x
Adjustable Startup Time	
AmpDim	
Auxiliary Power Supply Voltage	x
Constant Light Output	x
Constant Light Output Multi-Channel	x
Coded Light	x
Coded Light Randomize	x
Coded Mains	x
Coded Mains Standalone Receiver	
Correlated Color Temperature Dual Channel	x
Corridor Mode	x
DALI 102	x
DALI 202	x
DALI Power Supply	x
Daylight override / Daylight switching	
Device Info	
Dimming Interface	
DiiA specification DALI Part 253 - Luminaire Maintenance	
Driver addressing	
Driver Temperature Limit Driver Temperature Limit for Lock	
Dwell Time	
Dynadimmer Dynadimmer With Flextune Dynadimmer Dual Channel	x
DC Emergency	
End Of Life indication	

FCC	
FccRed	
FlexTune	x
Field Task Tuning	
Field Task Tuning/ Occupancy Sensing / Daylight Harvesting	
Lamp Burn-in	
Lamp Selection	
Light Source Operating Hours	
LineSwitch	
Load Fault Indicator Thresholds	
Logical Signal Input	x
Luminaire (Fixture) Information	x
Luminaire Production Test	
LumiStep	
Min Dim Level	x
Motor Control	
Module Temperature Protection	x
NTC on LEDset	x
Occupancy Sensing / sDaylight Harvesting	
Occupancy sharing / Group light behavior	
OEM Write Protection	x
Push Button Unit LCU2070	
Push Button Unit LCU2071	
Quick Lamp Start	
Relay Switched Output	
Self Contained Emergency	x
Set Lamp On Time	x
SR Power Supply	x
Step Dimming	x
Summary	x
Touch and Dim	x
Tx Power	

TBD

11.26 Device-specific technical descriptions

For a detailed technical description of the characteristics of the devices, please visit the product-specific web sites:

Table 8 Product-specific web sites

Product group	Visit:
LED	**https://www.tci.it/**

11.27 Error handling

11.27.1 Reporting and correction of errors/warnings when reading from a feature configuration file

When, after opening a feature configuration file, incorrect parameters are detected, software tries to correct these parameters for the selected (virtual) device. When a correction is made, a red border will be shown. In cases when no logical correction can be made, an orange border will be shown.

11.27.2 Reporting of errors when reading from a device

When after reading from a device a mismatch is signaled between the parameters of the device and software, will not correct the parameters, but will show a red border.

11.27.3 Reporting of errors when entering incorrect values in a feature

Entering an incorrect value for a parameter will be indicated by a red border.

11.28 Troubleshooting

Problem: After starting software, no devices are displayed.
Solution: Click the **Scan network** button on the **Network** panel to start discovering the devices in the network. If the devices connected have already a DALI short address this will not be changed. Devices without a short address will be programmed with a short address. When the **Commission** button is clicked, the short addresses of all connected devices will be renewed, whether they already had a short address or not.

Problem: I would like to assign a specific short address to a device.
Solution: First scan the network for devices. Right-click the device you would like to give a short address and select **Set short address**.



A dialog window will appear in which you can enter the desired short address.



Click **OK** to program the short address into the device.

Problem: I would like to remove the short address of a device.
Solution: First scan the network for devices. Right-click the device whose short address you would like to remove and select **Reset short address**.



You will be informed that the short address was reset.



Problem: I would like to configure the special features of the connected device. **Solution**: After scanning the network for devices, a device has to be selected by clicking it in the **Network**. Select the **Device features** tab. The related features will appear. To update the view to the actual status of the features, click **Read** on the toolbar. If you now change any of the features, and want this to be stored into the device, click **Write** on the toolbar.



Problem: I would like to know more technical details of a device.
Solution: Please refer to the website for more detailed information

TBD

TBD