

TCI Driver Configurator USER GUIDE

This user guide provides instructions on how to program TCI TW LED driver parameters, how to configure colour control features, and provides guidance for the use of the TCI Driver Configurator program.

PARAMETER SETTING WITH TCI TW DRIVER CONFIGURATOR

The TCI TW Driver Configurator tool is divided in tabs for ease of use. Once device data is red, all functions not supported by the connected driver will appear as disabled and not accessible. The configuration tool includes text fields where parameters can be modified: by typing into information fields or pressing buttons to select/enable/disable functionalities. An "Upload" button in the "Device Parameters" tab uploads the modified parameters into the connected driver.

The program is used to control and program manually or automatically the connected drivers. Also driver address copying and physical driver identification features are available.

The program is used for customizing the LED driver for a specific need. Following selection of configurable LED driver parameters are available:

- Device identificaton & addressing
- Driver settings
- Automatic programming
- Command programming
- TW e DALI settings

e DALI settings allow TW LED configure module to parameters and driver parameters affecting the control of colour temperature in order to ensure a proper operation of colour and intensity control with TCI Tunable White LED drivers (TW Series).

DALI LED Module power supply USB to DALI interface DA+ SC DA CI (TW) LED Driver

DA+ DALI

DA-

ELECTRICAL CONNECTION

Safety warning: remember to turn off the electricity before disconnecting or connecting devices. Only a trained person should be doing this!

The connection between the programming PC and the driver can be established for example with the following setup:

- Devices needed:
 - DALI power supply.
 - HTW PROGRAMMING TOOL.

For installation of the software, run the installation file. Supported operating system is Microsoft Windows 7 and compatible.

Preliminary setup: The USB to DALI Interface unit is connected to the DALI power supply, and the driver under configuration with DALI bus. Please ensure correct polarity of the USB to DALI Interface and DALI power supply! TCI LED driver DALI bus connections are unipolar and require no special attention.

The DALI power supply and the driver under configuration must also be provided with mains power.

Example setup to use when using Helvar DALI Driver Configurator:

DALI



MAIN WINDOW

The main all sub ta selector, s identify bu

WINDOW nain part of the Configurator window is common for ub tabs showing selected adapter selector, address tor, scan bus, assign short addresses, read data and fy buttons.	Adapter USB Read Data Name GTIN Serial Sw Version Device Parameters C	Address
TCI Adapter Address USB< ▼ Read Data Identify	s Ass	gn short adc
Name Adapter COM5 connected!	Load	ave Upload Write short address

TCLE TCI

MAIN WINDOW BUTTON FUNCTIONALITIES

Adapter selector	Select USB or COM port for DALI communication. USB selection always refers to a connected "HTW PROGRAMMING TOOL" USB to DALI converter, while COM port might be any serial device. The user should know the actual COM port for their serial to DALI converter.
Address selector	Select the DALI address of the device. Use "Scan bus" to populate the list (initially the list is empty).
Scan Bus	Scans through DALI short address space to find devices connected to the selected DALI adapter. Updates the address list with found short addresses and device names.
Assign short ddresses	When checked, the "Scan Bus" process (see above) assigns new short addresses to devices that lack them or devices with conflicting addresses. Already assigned unique short addresses are left as they are. Note: it's also possible to configure unaddressed devices if they are the only device currently on the DALI bus.
Read Data	Reads the current configuration from the selected device. The configuration can then be edited in "Device Parameters" tab below.
ldentify	The selected LED driver changes between MIN and MAX values, so it's possible to physically identify which device is currently being configured. Use this feature together with address selector to program a desired driver in an installation.



DEVICE PARAMETERS		A DALLY TUNAble White		*	L
		Ch1 (cool) (K)	Ch2 (warm) (K)		
After reading the configuration from a selected device using "Read Data" button, the "Device Parameters" tab displays the features of the device which can be altered. Please note that only available settings for the connected device model are displayed.		Ch1 (cool) (lm) 500 Power on colour 5000 Power on level 254 System failure colour	Ch2 (warm) (lm) 1000 Power on level % 100	Power on last colour enabled Power on last level enabled	
GENERAL BUTTONS		5000 System failure level	System failure level	System failure colour disabled	
Load	Load configuration from file. The parameters supported by the device type will be shown in "Device Parameters" tab.	Linear Dimming Curv Minimum Level Maxi 85 254	re mum Level	System failure level disabled	
Save	Save configuration to a file.	NTC			
Upload	Uploads the current parameters to the device selected by "Adapter" and "Address" selectors.	Switch Control	ed		

Device Parameters Control Automatic Mode

DEVICE DEPENDENTLY AVAILABLE SETTINGS

Switch Control Enabled	 Selecting this radio button enables the functionality if it is supported by the LED driver. Power On Last Level Enabled – selecting this lights return to the last DALI level used before the power break.
lset by SW	Select this to override current setting via multipurpose Iset-terminal in the driver. The same driver terminal can then be utilized for other functions like the NTC operation.
Output current	Type in the driver output current in mA. If the value is outside of the LED driver output current range the driver will use the closest specified value. The drivers use the smallest output current as a default.
NTC Enabled	Select this feature to protect luminaire from critical high temperatures.
NTC value	Type in the NTC value corresponding to the trigger temperature. If supported the NTC value is speci- fied on each TCI LED driver datasheet.
CLO Enabled	Select this to compensate against light depreciation of the light source. CLO Start level (%) – type in desired light level to maintain Constant Light Output CLO Life Time (x1000 h) – type in desired lifetime in thousand hours. This time describes when the output current needs to be on 100% level to maintain the selected Constant Light Output.
Write short address	When checked, also a short address is set during upload. This can be is useful if you want to copy the whole state of another device including the short address (read data from one device, select a new compatible device and upload with this option checked). If you want to change device address to some other value see "New short address" in "Control" tab.



CONTROL

Light level

Driver operation can be tested in control window, where light level and colour temperature can be changed. Also power on level and system failure level can be set; these settings can be also adjusted in "Device Parameters". Driver addressing and address removal are also possible.

Real time control to set

Device Parameter Control Jutomatic Mode	
Light Level	
	254
Set as power on level Set as system failure level	
Active Colour Temperature	
	5000
Set as power on colour Set as system failure colour	
New Short Address	
1 Set Remove	

	the light level of the device.
Set as power on level	Sets current light level as power on level in the configuration. Note: Click the "UPLOAD" button to transfer the setting to the driver.
Set as system failure level	Sets current light level as system failure level in the configuration. Note: Click the "UPLOAD" button to transfer the setting to the driver.
Active colour temperature	Real time control to set the colour temperature for Tunable White devices.
Set as power on colour	Sets current colour temperature as power on colour in the configuration. Note: Click the "UPLOAD" button to transfer the setting to the driver. Only available with Tunable White devices.
Set as system failure colour	Sets current colour temperature as system failure colour in the configuration. Note: Click the "UPLOAD" button to transfer the setting to the driver. Only available with Tunable White devices.
New short address	Select a new short address (1-64) for the device. The new short address is written using "Set" button.
Remove short address	Removes the short address from the device. Unaddressed devices can be configured when they are the only one on the DALI bus, in this situation TCI Driver Configurator uses a special "broadcast" address.

AUTOMATIC MODE

Automatic upload is a feature for serial configuration of LED drivers. When activated, the DALI bus is polled constantly to find devices compatible with current configuration and the settings are transferred to the device. The current configuration can be seen as a list in this view. This function allows multiple drivers to be programmed one after one, for example in luminaire manufacturing environment.

The settings for the Automatic Programming Mode are set in "Device Parameters". The parameter containing file can also be loaded in the "Device Parameters" and used in the Automatic Programming Mode. The parameter settings to be uploaded are listed in the "Automatic Mode" window.

AUTOMATIC UPLOAD

Safety warning: remember to turn off the electricity before disconnecting or connecting devices. Only a trained person should be doing this!

When waiting and scanning the bus, the green color indicator is shown - the user is free to connect new devices to the DALI bus.

TCL TCI Adapte USB Scan Bus Assign short addres Read Data Nam GTIN 6418488553309 Serial 970046 Sw Version 14.6.49 Device Parameters Co Paramete NTC enabled FALSE Switch Control Enabled FALSE Ch1 (cool) (K) 5000 Linear Dimming Cu FALSE Ch2 (warm) (K) 1000 Ch1 (cool) (lm) 500 1000 Ch2 (warm) (Im) Power on level 254 ower on colour LOUF System failure leve 254 ystem failure colou 5000 Maximum Level 254 Minimum Level 85 utomatic upload

During the upload the colour indicator is red.

Do not turn off LED drivers while the upload process is not finished.

Status box shows information about the state of the automatic uploading process.

When all your devices are configured, click "Automatic mode" button again to exit.

Note: Either multiple drivers with no address, or one driver with an address can be programmed.

TW COLOUR CONTROL



Following settings are available only for TCI TW DALI device type 8 drivers for colour control.

TW & DALI SETTINGS

TW is TCI's solution for LED drivers and lighting control systems supporting DALI device type 8 functionality for colour control. The DALI standard defines a subgroup 209 (devices type 8) for colour control of LED drivers. In order to achieve actual colour control of the LED driver, specific DALI colour commands are sent.

The driver must support multiple output channels, which are controlled individually. Two channels are used for tunable white, and up to four for RGBW (red, green, blue and white). DALI device type 8 can control these multiple channels using only one DALI address, allowing for more devices on each DALI subnet. Note that colour temperature calculations are made in Mired units to ensure the most accurate performance and the best result for tunable white solutions. Using Mired units corrects the non-linearity of colour temperature on Plancian Locus Curve. This conversion on LED driver calculations from mireds to Kelvins show rounding to actual Kelvin values displayed.

$$Mired = \frac{1000000}{Kelvin}$$

PARAMETERS AVAILABLE

Ch 1 (cool) Tc (K)	Defines colour temperature for Channel 1 cool white LED.
Ch 2 (warm) Tc (K)	Defines colour temperature for Channel 2 warm white LED.
Ch 1 (cool) TY (lm)	Defines lumen output for LED module(s) connected in Channel 1.
Ch 2 (cool) TY (lm)	Defines lumen output for LED module(s) connected in Channel 2.
Power On Colour (K)	 Defines colour temperature where the lights turn ON after mains breakage. Power On Last Colour Enabled – by selecting this button the light will return to the last colour temperature used before mains breakage.
Power On Level (0-254)	 Defines the light level where the lights switch ON after a mains break. Next to this text field is an indication of the selected level in percent value. Power On Last Level Enabled – by selecting this button the lights return on last DALI level used before the power break.
System Failure Colour (K)	 Defines colour temperature where the lights go if the DALI line disappears. System Failure Colour Disabled – select this button if no operation is required after system failure.
System Failure Level (0-254)	 Defines the DALI level where the lights go if the DALI line disappears. Next to this text field there is an indication of the selected level in percent value. System Failure Level Disabled – select this button if no operation is required after system failure.
Linear Dimming Curve	Select to use linear dimming curve. The DALI curve as default is linear for the human eye.



"COMMAND LINE" MODE

TCI Driver Configurator can also be used to transfer configurations without human interaction and without opening the normal operating window. This is mostly useful when LED drivers are configured as a part of an automated (luminaire testing) process. When preferred settings for the device in the graphical user interface has been created, save them to a file. This file can then be transferred to the device using command line arguments.

Note: Either multiple drivers with no address, or one driver with an address can be programmed. Note: The application must be run from the install directory

SYNTAX

TCIDriverConfigurator.exe <filename> <flags> NOTE: file names with blank spaces are not supported

Flags that can be used:

-p <	port>	Adapter port to be used. USB for TCI HTW PROGRAMMING TOOL, or COM1 COM99 for serial. Default: USB
-a <a< td=""><td>address></td><td>Short address of the device</td></a<>	address>	Short address of the device
-b		Use broadcast address. Can be used if there is only one device on the bus, even when using a device with no short address set.
- S		Scan DALI bus for compatible devices and upload the configuration to all of them
-x		Program missing or conflicting short addresses. This is used with the "scan" option in case the user wants to set new short addresses to devices without them (or have conflicting addresses). This is basically the same functionality as "assign short addresses" in User Inter- face mode. Already programmed unique short addresses are left as is.
Note:	: flags -a, -	b, -s all concern the device address so they are mutually exclusive

Example: TCIDriverConfigurator exampleconfiguration.json -a COM19 -s -x

This command transfers configuration file "exampleconfiguration.json" using adapter port COM19 (serial device), scans the DALI bus for compatible devices, and programs short addresses automatically.

RETURN VALUES

TCI Driver Configurator exits with an error code giving information about the operation. If TCI Driver Configurator is used as a part of an automated system, this return value can be handled in the script or application it is called from.

- SUCCESS
- 1 ILLEGAL ARGUMENT
- 2 FILE NOT FOUND
- 3 ILLEGAL CONFIGURATION FILE
- 4 MULTIPLE RESPONSE
- 5 NO RESPONSE
- 6 DEVICE NOT COMPATIBLE
- 7 PORT NOT AVAILABLE
- 8 VERIFY FAILED
- 9 UNKNOWN ERROR
- 10 DALI BUS EMPTY